

NOTES FOR SERVICE RELOCATION/ABANDONMENT

- Contractor is responsible for locating all on-site utilities prior to construction. Damage to existing utilities during construction is the responsibility of the contractor.
- Existing water service lines on the short side of lot that will not be used must have service pipe cut and plugged at corporation stop connection at waterline.
- Existing water service lines on the long side of lot that will not be used must have service pipe cut and plugged at corporation stop connection at waterline and at back of curb on both sides of the street. Water service line under the street to be abandoned.
- All existing 6" and larger pipe to be abandoned within public or private right-of-way must be grout-filled and disconnected to existing/active infrastructure.